

Please read these instructions carefully before assembly and first use and keep them in a safe place!

IMPORTANT: SAFETY INFORMATION

To avoid possible damage, read and follow the instructions below:

Danger to life due to interference with pacemakers or defibrillators (ICD) by static magnetic fields! Always keep a sufficient distance between TWIST products and pacemakers or defibrillators (ICD).

Risk of injury from use in extreme sports! Remove TWIST products from your equipment before engaging in extreme sports. Do not use TWIST products while doing extreme sports.

Risk of injury due to defects of any kind that have occurred in TWIST products! Immediately discontinue use and contact specialist dealer.

Intended use

TWIST is a magnetic-mechanical holder system consisting of base (Fig. A) and connector (Fig. B).

The intended use of the TWIST bottle connector left turn is mounting and use on a TWIST bottle 450/590/590 antibacterial/600/750 compact in combination with a TWIST bike base/uni base.

The TWIST bottle connector left turn is not compatible with the TWIST tex base, the TWIST tex base multi (Fig. F) or the TWIST belt only products (Fig. G)!

The TWIST bottle connector left turn may only be used with the original and compatible TWIST products. Otherwise, the mechanical engagement cannot take place.

Any use that deviates from this intended use is considered improper and can lead to injuries, damage or malfunctions.

TECHNICAL DATA

Compatibility: TWIST bike base, TWIST uni base, TWIST bottle 450, TWIST bottle 590, TWIST bottle 590 antibacterial, TWIST bottle 600, TWIST bottle 750 compact

No compatibility: TWIST tex base, TWIST tex base multi, TWIST belt only products

Material: PA66GF, neodymium, epoxy, stainless steel, silicone
Made in China

ASSEMBLY

If you are unsure about the installation, ask your retailer for advice!

▲WARNING Risk of injury if used with unsuitable products! Only use original and compatible TWIST products intended for use with the TWIST bottle connector left turn.

1. Insert the TWIST bottle connector left turn into the recess on the TWIST bottle (Fig. C). The **FIDLOCK logo on the TWIST bottle connector left turn must point upwards, be legible and not "upside down"** (Fig. D). **The arrow on the slot must point to the open lock symbol**.
2. Turn the slot on the TWIST bottle connector left turn clockwise with a coin or Allen key until the arrow points to the closed lock symbol (Fig. E).

USE

▲WARNING Risk of injury from use in extreme sports! Remove TWIST products from your equipment before engaging in extreme sports. Do not use TWIST products while doing extreme sports.

▲WARNING Risk of injury from dirt on the base and/or connector! Before each use, make sure that the base and connector are free from dirt. Clean the base and connector immediately by hand with clean water if they become dirty.

▲WARNING Risk of injury if used with unsuitable products! Only use original and compatible TWIST products intended for use with the TWIST bottle connector left turn.

CAUTION Material damage due to heating or cleaning in the microwave! Do not heat or clean TWIST products in the microwave.

CAUTION Property damage due to storage in the freezer! Do not put TWIST products in the freezer.

CAUTION Material damage due to extreme temperatures! Use TWIST products only at outdoor temperatures between approx. 0°C (32°F) and 40°C (104°F).

Before setting off, familiarise yourself with the handling of the TWIST bottle connector left turn and check that it is working properly. Make sure that the assembly has been carried out properly.

To use the TWIST bottle connector left turn on a TWIST bike base/uni base follow the instructions for use of the TWIST bottle.

CLEANING

CAUTION Material damage if cleaning the TWIST bottle connector left turn in the dishwasher! Do not clean the TWIST bottle connector left turn in the dishwasher. Disconnect the TWIST bottle connector left turn from the TWIST bottle before putting the TWIST bottle in the dishwasher. Clean the TWIST bottle connector left turn only by hand with clean water.

CAUTION Material damage due to heating or cleaning in the microwave! Do not heat or clean TWIST products in the microwave.

Before cleaning the TWIST bottle: Disconnect the TWIST bottle connector left turn from the TWIST bottle

1. Turn the slot on the TWIST bottle connector left turn anticlockwise with a coin or Allen key until the arrow points to the open lock symbol (Fig. E).
2. Remove the TWIST bottle connector left turn from the TWIST bottle.

STORAGE

CAUTION Property damage due to storage in the freezer! Do not put TWIST products in the freezer.

Store the TWIST bottle connector left turn in a dry place.

DISPOSAL

The TWIST bottle connector left turn can be disposed of in household waste. Please observe the applicable environmental regulations in your country regarding disposal.

LIABILITY

We have gone to great lengths to ensure that the operating instructions are correct, complete and as precise as possible. However, deviations cannot be entirely ruled out, and no liability can be accepted for errors in the operating instructions provided.

We accept no liability for damage caused by failure to observe the instructions for use or by improper use.

If the TWIST bottle connector left turn is misused, used improperly or repaired without authorisation, no liability will be accepted for any damage.

LEGAL INFORMATION

The TWIST technology is legally protected by one or more patent(s)/patent application(s). For more information on the patent protection of the TWIST product range, please visit: www.fidlock.com/patents

See our website for more information: www.fidlock.com/consumer

FIDLOCK GmbH, Kirchhorster Straße 39, 30659 Hanover, Germany,
AG Hanover, HRB 204281, Email: info-bike@fidlock.com

FIDLOCK®

